


Origami Coin Purse

Tools & Materials




Paper Cutter




Scissors



Ruler




Iron




Press Snap Buttons Toolkit



Hammer




Parchment Baking Paper




Plastic Bags

How To Fuse The Plastic Bags



Regular Iron
Set up the minimum temperature

Parchment Baking Paper
(enough paper to cover the plastic bag material)



4 to 6 layers of plastic bag material
12cm x 30cm
(adding more layers will create a more rigid fabric)

Notes:


01. Sandwich the plastic bag material between the baking paper. Start with two layers and add layer by layer after you fuse the previous ones.

02. Keep the iron moving while you are fusing the plastic bags until you see all the layers are fused together. Peek under the baking paper to check the plastic layers often.

03. When you have your fused plastic material, use a ruler and a paper cutter to cut it using the template provided in page 02.




Origami Coin Purse




Tutorial


01.
fold a-b
(this is
the back
side)




02.
fold b-c










03.
fold a-c



04.



-  cutting line
-  mountain fold
-  valley fold
-  press snap button cap
-  press snap button stud
-  press snap button socket
-  press snap button post

